


В



Note that only one side of these Inside Corner Brackets slides in all the way.

Exact locations don't matter yet.


The short red extrusions are for squaring the frame and will be removed later.

ITEM NO.	DESCRIPTION	QTY.
1	604mm long TSlot Extrusion	2
2	Interior Inside Corner Bracket	8
3	74mm Temporary TSlot Extrusion for Squaring	2

Upper Frame Squaring Setup			
<u>cc</u>	<b>(i)</b> BY	Created by: Joshua Vasquez	last edited: 10/25/2020
		SCALE: 1:4	SHEET 2 OF 11


Α

В



Slide two 25-50-75mm (or 1-2-3) Blocks into the frame on either side and firmly clamp the entire setup together as shown above.

Notice that the red extrusions will be loose. This is intentional as they are not being used as references to square the frame. In this configuration, the frame is "square" using the 1-2-3 Blocks as a reference.




В

Α

В

Upper Frame Bracket Registration			
	Created by:	last edited:	
BY	Joshua Vasquez	10/25/2020	
	SCALE: 1:3	SHEET 3 OF 11	



Using Calipers as a reference, adjust the red extrusions such that they match the dimensions shown above. Note that bracing the entire assembly against a loose extrusion may make this dimension easier to measure as shown below. When they are in the proper location, fasten down all 16 screws in the inside corner brackets. This procedure will fix the brackets in the correct location.




В

Upper Frame Bracket Fixturing				
	Created by: last edited:			
BY		Joshua Vasquez	10/25/2020	
		SCALE: 1:3	SHEET 4 OF 11	

CC


В


.



Like before, assemble the entire lower frame without fastening down any set screws.

В





ITEM NO.	DESCRIPTION	QTY.
1	409mm TSlot Extrusion	4
2	604mm long TSlot Extrusion	2
3	Interior Inside Corner Bracket	18

Lower Frame Loose Assembly			
<u>@</u>	<b>(i)</b> BY	Created by: Joshua Vasquez	last edited: 10/25/2020
		SCALE: 1:5	SHEET 6 OF 11


В

.

В

Make 8 of the following assemblies.

В



A

ITEM NO.	DESCRIPTION	QTY.
1	Outer Frame Squaring Plate	8
2	M5 Buttonhead Screw, 10mm long	16
3	M5 Drop-In T-Nut for 20x20 Extrusion	16


Squaring Bracket Assembly				
(32)	<b>(</b> )	Created by: Joshua Vasquez	last edited: 10/25/2020	
		SCALE: 1:1	SHEET 7 OF 11	

Join the prior frame with the loose frame "back-to-back" such that the dangling corner brackets do not interfere with each other. Then install the 8 plate assemblies into the corner and tighten them down such that the frame is "pulled" into the shape by the frame from the prior step.


Note: This process is made easier by dangling the frame over a table such that the corner brackets do not prevent the frame from resting flat on

the table surface.

В



Clamp down the outer frame with the temporary red plates as shown below. This step will pull the lower frame into a configuration that matches the upper frame. Then clamp down the setscrews in the outer frame extrusions. (The inner extrusions will be clamped down later.)



Upper/Lower Frame Registration			
(00)	<b>()</b>	Created by: Joshua Vasquez	last edited: 10/25/2020
		SCALE: 1:5	SHEET 8 OF 11

2


-

Д

В

Now tighten down the setscrews in the outer frame extrusions on the frame that is still loose. (The inner extrusions will be clamped down later.)


В




A

Lower Frame Bracket Fixturing				
<u></u>	<b>(</b> )	Created by: Joshua Vasquez	last edited: 10/25/2020	
	_	SCALE: 1:5	SHEET 9 OF 11	

В







2

В